

Qty	Description
3	PLANATARY KIT; KOMATSU; FINAL DRIVE AK5524
2	CYLINDER; HOIST; KOMATSU; REPAIRED; EL4835
5	BRAKE DISC REPAIR KIT KOMATSU 58C-00-00030
2	TANK ASSY; HD1500-7; XC4895 & 01573-20207; KOMATSU
1	BRAKE ASSY; RECONDITIONED; KOMATSU; 562-33-30110
1	BRAKE ASSY; KOMATSU; 562-33-30110
2	DECK; RH; KOMATSU; EM2841
2	HUB; HD1500; KOMATSU; 562-27-31214
11	BEARING; MODEL;330M ;WA900;WA900-3EO; KOMATSU; 561-22-62980
1	SUSPENSION CYLINDER; REAR; R/H REPAIRED; KOMATSU; EL7969
2	TANK ASSY; BODY; KOMATSU XC4895
1	CABLE ASSY KIT; 58B-00-00820
3	SUSPENSION CYLINDER; FRONT R/H ;REPAIRED; KOMATSU; EM5220
2	SEAL; ASSY; KOMATSU; 562-33-00013
5	WIRING HARNESS; KOMATSU; XC3510
10	LINK; MASTER; K.L.H
5	KIT; ARM FRM; FRONT; KOMATSU HD1500-7; AK3664
5	COUPLING ASSY; 6553-91-3600; KOMATSU
1	MOTOR; INVERTER MONITORING; KOMATSU; QS0211
1	MOTOR; INVERTER MONITORING; KOMATSU; QS0212
2	TIE ROD; STEERING; KOMATSU; EL8338
1	RADIATOR ASSY; REPAIRED; KOMATSU PC1883
2	VALVE; REAR BRAKE COOLING; HD1500-7 KOMATSU; EF5019
2	PIN; KIT; STRG; CYL; INNER; KOMATSU HD1500-7; AK3666
6	TEST BLOCK ASSY, DANFOSS; LH2350 P & H LOADER; KOMATSU; R4219622
53	LIGHT; HEADLIGHT ASSY; HID KOMATSU; XA5128
5	TIE ROD END LH THREAD EL5207
3	KIT; LEAF SPRING; REAR SUSP; KOMATSU HD1500-7; AK4207
2	RIM, WHEEL, BASE; PNEU; TYRE; KOMATSU; AK5100
1	DOOR; ASSY; L/H HD1500-7 KOMATSU; AHEM0048
16	PAD; CHASSIS; DUMP BODY HD1500-7; KOMATSU; AHTW8650
1	PARTS KIT; LEAF SPRING ASSY; REBUILT; FRONT SUSPENSION; KOMATSU; AK4206
3	EXHAUST TUBE - LH; KOMATSU; XC2292; XC4924
5	TIE ROD END RH THREAD EL5206
5	ADJUSTER; SLACK; KOMATSU; BF3289
2	BOX; LOUVER GRID; KOMATSU TRUCKS 860 & 960; 58B-43-00020
1	HARNESS; TRANSMISSION; KOMATSU HD1500 ;562-06-31710
6	FLANGE STR; SUB COMPONENT OF BODY EXHAUST COUPLING; EJ4467; KOMATSU HD1500-7;EF!
3	CABLE; CHASSIS; DUMP BODY HD1500-7; KOMATSU; AHEF4599
25	RING; SNAP; 707-88-03881; KOMATSU
3	CABLE; BODY RETENTION; KOMATSU EF4599
2	BODY; OUTER; KOMATSU HD1500-7; 562-01-32141
10	PIN; 562-40-31340

2 KIT,GREASE PUMP 58F-00-40870  
23 ELEMENT; KOMATSU; 561-15-55660  
1 TUBE ASSY; KOMATSU; EM6357  
1 KIT; METER; KOMATSU; 58B-06-00800  
3 EQUALIZER; KOMATSU HD1500-7; PB6977  
3 VALVE; COOLING; KOMATSU; 561-60-62201  
1 CONTROLLER; KOMTRAX PLUS; KOMATSU; 7826-17-1505  
1580 SEAL; RUBBER; KOMATSU HD1500-7 XA2720  
1 PIN KIT; STRG; KOMATSU; AK3666  
3 SWITCH ASSY; KOMATSU; XA4145  
1 BEARING; KOMATSU; 562-27-31921  
2 TYRE RIM FLANGE; KOMATSU; AK5101  
1 DRIVE SHAFT; PC5500 KOMATSU; 79365273  
1 COVER; KOMATSU; 562-01-32114  
2 MANIFOLD BLANK; STEER BASE; L-2350 LOADER; KOMATSU; R4290368  
2 VALVE PORT; XA0066  
1 SHROUD; FAN; RADIATOR; KOMATSU HD1500-7; AHPC0597  
1 MOTOR ASSEMBLY; KOMATSU 708-7T-00750  
4 PANEL; MOULDED; KOMATSU 1500; EL1060  
1 FIRE SUPPRESSION CONTROL KIT; PAFSS; 4KG KOMATSU  
3 CONTROLLER , DISPLAY UNIT, KOMATSU HD1500 ,WATER TANK, 201-240-59  
1 ACCUMULATOR; HYD; KOMATSU; PC2196  
2 VALVE; CHECK; PB9681  
4 BLOCK; DISTRIBUTION; KOMATSU PC5500; 65036840  
1 ARM; REAR; RADIUS; TOP; 562-52-31310  
112 SHIM; T=1.6MM; 562-74-31620  
3 TUBE; KOMATSU; EH3376  
1 AIR CLEANER GROUP; KOMATSU; HD1500-7; PC2556  
1000 SEAL; RUBBER; KOMATSU HD1500-7 XA2721  
5 BRACKET; VEHR; KOMATSU HD1500-7; EK6488  
1 BOX ASSEMBLY SERVICE CENTER; HD1500 KOMATSU; EG8913  
10 KIT; PACKING; KOMATSU; 1287543H1  
5 RING; LOCK; KOMATSU HD1500-7; AK-5113  
1 CONTROLLER; VHMS ; KOMATSU; 7826-17-8501  
4 VALVE; 3"; WATER , COMPLETE; KOMATSU HD1500 ,WATER TANK, 201-275-25  
1 VALVE ASSY  
2 ELEMENT; 600-651-1610; KOMATSU 475  
4 SENSOR; ANGLE SENSOR; KOMATSU HD1500 ;7861-93-5330  
20 STRUT; GAS; OIL SUSPENSION; KOMATSU; VJ3911  
1 WIRING HARNESS; KOMATSU; XC3509  
2 WIRING HARNESS; XC3505; KOMATSU HD1500 ;  
2 TIMER; AUTO LUBE; KOMATSU HD1500-7; PC2667  
3 PEDAL ASSEMBLY; KOMATSU 702-16-07022  
2 HARNESS; EL3237 ; KOMATSU HD1500-7;

4 VALVE; CLICKON; ENGINEERING; TOP TECH; KOMATSU HD1500-7; 201-235-46  
1 CONTROL ATC; KOMATSU HD1500-7; 7818-63-1000  
1 HEAD; 562-40-31230; KOMATSU HD1500  
1 HEAD; 562-40-31240; KOMATSU HD1500  
1 CASE; KOMATSU HD1500; 562-06-31410  
11 NOZZLE HOLDER ASSEMBLY; KOMATSU ; RM6212-11-3202  
1 CABLE; BODY RETENTION; KOMATSU HD1500-7; EF4599  
2 DISPLAY; WATER TRUCK; ENGINEERING TOP TECH; 201-240-69  
10 COVER; 581-40-11151  
1 VALVE; KOMATSU HD1500-7; 562-13-56401  
2 BRACKET; 562-06-31380  
4 CAMERA; WATER TRUCK; HD1500 ENGINEERING TOP TECH; 201-000-67  
2 TIE ROD; STEERING; REPAIRED KOMATSU; EL8338  
5 SOLENOID; VALVE; BRAKE COOLING; KOMATSU 702-21-07930  
2 CAMERA; DISPLAY; ENGINEERING; TOP TECH; KOMATSU HD1500-7; 201-000-68  
3 HOSE; NONMTL; KOMATSU; HA7235  
4 HOSE; SR COOLANT; 2.00 112.00; LH2350 P & H LOADER; KOMATSU; R4275554  
11 CLAMP; EXHAUST; KOMATSU HD1500-7; AHPB6183  
1 SEAT; VEHR; SUSPENSION; KOMATSU; XA 4007  
1 HAND RAIL; LH; KOMATSU HD1500-7; EM3914  
2 COMPRESSOR; RECIP; AIR; 905; KOMATSU; PC1816  
1 VALVE; PPC ASS'Y KOMATSU 702-16-35001  
18 HOSE; NONMTL; KOMATSU HD1500-7; EM0492  
3 BRACKET; MUD FLAP; HD1500-7 DUMP TRUCK; KOMATSU; 562-06-31630  
1 LADDER; RH; HD1500-7 KOMATSU; EM2664  
1 CONTROLLER; HD1500; KOMATSU DAMP TRUCK; 7826-13-3504  
3 TUBE; BRAKE COOLING; KOMATSU; EM6883  
1 PARTS KIT; OEM; MAJOR SERV; KOMATSU HD1500-7; BF3253  
1 ROD; 562-40-31220; KOMATSU HD1500  
22 ROD; PACKING; 707-51-75860; KOMATSU  
2 INDICATOR; KOMATSU HD1500-7; XA3850  
2 VALVE; KOMATSU; 562-15-34000  
2 PIN; 562-46-32570; KOMATSU HD1500  
1 BOX, QUICK FILL; HD1500 KOMATSU; TZ8035  
1 FILTER ASSY; KOMATSU; EH3676SERV  
2 PAD; BODY; KOMATSU; TW8650  
1 OIL PUMP ASS'Y KOMATSU 6219-51-1000  
2 SENSOR; BRAKE; WA1200 WHEEL LOADER; KOMATSU; 42C-43-19210  
3 GASKET; OIL PAN ADAPTER; KOMATSU HD1500; 4101117  
16 WASHER; KOMATSU HD1500 WA1200 42C-01-11151  
58 RING; BACK-UP; 707-35-90810; KOMATSU  
2 BLOCK; JUNCTION; HD1500-7 KOMATSU; EF4145  
2 SUPPORT; HD1500-7 KOMATSU; EK5588  
2 BRACKET; 427-S33-2410; KOMATSU

2 HOSE; ASSY; 1.5IN X 50 W/ENDS; KOMATSU 785-7; WATER BOWSER  
22 RING; BUFFER; 707-51-75650; KOMATSU  
1 QUILL; HD1500-7 KOMATSU; EL3414  
1 PEDAL; ELECTRONIC; KOMATSU; XK1205  
2 DRIVER CARD ; SOLENOID ; 305078  
1 CYLINDER ASSY; STEERING; RECONDITIONED; KOMATSU; 707010F500  
4 DRYER; RECEIVER; COVER; HD1500 KOMATSU; EM3942;  
5 PLATE; MTL; KOMATSU HD1500-7; EH8744  
4 BRACKET MIRROR; 562-54-32520; KOMATSU HD1500  
8 VALVE; BYPASS; KOMATSU HD1500-7; BF3306  
2 BUSHING; KOMATSU HD1500-7; 707-52-91551  
23 SEAL; DUST; 707-56-75820; KOMATSU  
6 RING; EXHAUST BODY NA COUPLING; KOMATSU HD1500-7; EJ4467  
1 JACK; CYLINDER; ENGINEERING TOP TECH; 183-382-53-00  
6 BREAKER; CIRCUIT; 12.5 AMP; KOMATASU HD1500-5; PC1385  
2 MIRROR ASSY; REARVIEW; CONVEX; PB7491  
2 WIPER ASS'EMBLY; KOMATSU HD1500-7; AHPC1794  
8 RESISTOR; KOMATSU; XA4478  
1 CORE KIT; KOMATSU; BF3370  
1 HOSE; NONMTL; KOMATSU; HA7224  
1 HOSE; KOMATSU HD1500; 562-61-31550  
4 VALVE; SOLINOID KIT; HD1500-7 KOMATSU; VE9079  
1 WIRING HARNESS; HD1500-7 KOMATSU; XC0417  
14 CLAMP; EK2834 ; KOMATSU HD1500  
1 VALVE; BLEED; DOWN; KOMATSU; HA6182  
1 TUBE; BRAKE COOLING; KOMATSU; EM6883  
22 CLAMP; HYD HOSE; KOMATSU HD1500-7; WB0988  
19 HOSE; NONMTL; EXT; KOMATSU HD1500-7; PB9927  
24 BOLT; M/C; KOMATSU; 562-20-12811  
4 STEP; KOMATSU; 561-54-8A810  
1 PLATE; METAL; KOMATSU HD1500-7; EL4382  
1 T/C SVC KIT; HD1500-7 KOMATSU; 562-13-05070  
1 PIN; KOMATSU; EF4305  
1 PARTS KIT; COMPRESSOR; KOMATSU HD1500-7; VE8721  
6 SEAL SET; STEERING CTRL VLV; HD1500-7 KOMATSU; BF3287  
4 RECEPTACLE; ASSEMBLY; KOMATSU; PB9112  
16 SCREW; CAP; SKT HD; KOMATSU; EF8255  
10 TUBE; HD1500-7 KOMATSU; BF5336  
1 GUARD; LOWER; RH; HD1500-7 KOMATSU; AHM4248  
2 ACCUMULATOR; HYD; KOMATSU; HD1500-7; PC2267  
1 HOSE; VALVE; BLEED; DOWN; KOMATSU HD1500-7; HA6182  
3 CONTROLLER; KOMATSU HD1500-7; ANTKS-B210B0  
1 HOSE; NONMTL; KOMATSU; HA3422  
1 HOSE; NONMTL; KOMATSU HD1500-7; HA8113

23 PLUG; 707-87-25090; KOMATSU  
1 HOSE; NONMTL; KOMATSU; HA8115  
12 BREATHER KOMATSU 6210-21-8711  
1 HOSE; NONMTL;STEERING; KOMATSU; HA7674  
2 TUBE; KOMATSU HD1500-7; 561-89-87652  
3 ADJUSTER; SLACK; BRK; KOMATSU; HD1500-7; EJ1838  
7 HOSE; KOMATSU HD1500; 02765-00469  
1 EVAPORATOR ASSEMBLY; D155 KOMATSU; ND446600-0991  
1 HOSE; NONMTL; KOMATSU; HA8371  
1 GUARD; UPPERR; L.H; HD1500-7 KOMATSU; AHEK2416  
2 O-RING; 426-15-49111  
1 COOLING COIL; AIR; DUCT TYPE; HD1500-7 KOMATSU; SM2513  
1 GUARD; LOWER; L H; HD1500-7 KOMATSU; AHEM4247  
2 BRACKET; VEHR; REF; COMPRESS; KOMATSU HD1500-7; 3411136  
1 BUSHING; KOMATSU HD1500; 3639974  
1 CASE; KOMATSU WA380 419-S30-2450  
7 MUD FLAP; HD1500-7 DUMP TRUCK; KOMATSU; AHEH0493  
1 RESISTOR; VAR; POTENTIOMETER; KOMATSU; XA2347  
1 SENSOR - STEERING KOMATSU HD785-7 HD1500-5  
10 ELBOW; KOMATSU; HD1500; 790-301-1530  
2 MOTOR ASSEMBLY; D155 KOMATSU; ND116340-7350  
24 SPRING; OUTER; 6210-41-4430  
2 JOYSTICK; WATER TRUCK; ENGINEERING TOP TECH; 201-240-68  
5 SPRING; SUB COMPONENT OF BODY EXHAUST COUPLING EJ4467; KOMATSU HD1500-7; 581-02-  
4 BAR; LADDER; STEP; KOMATSU; EC7230  
1 LINER; CYLINDER; KOMATSU HD1500; 4085917  
2 VALVE; CHECK; ASSEMBLY; KOMATSU; 6128-11-5304  
9 HOSE; NONMTL; KOMATSU HD1500-7; BF5072  
9 PLATE; 562-43-31110  
1 BODY; VALVE; HD1500-7 KOMATSU; 562-50-31200  
2 TUBE; KOMATSU; EM6282  
30 SCREW; KOMATSU HD1500; 3900637  
8 HOSE; ASSY; NONMTL; EXT; KOMATSU HD1500-7; EJ0350  
12 CASCREW; HEX; FLANGE HEAD; CUMMINS QSK78; KOMATSU 860/960 4006385  
1 MOTOR ASSEMBLY; KOMATSU HD1500-7; AN51500-10770  
1 COIL; HD1500-7 KOMATSU; VE8650  
1 TUBE; STEERING; CYL; LH KOMATSU HD1500-7; EK8136  
1 HOSE; NONMTL; FLEX; HD1500-7 KOMATSU; EH0170  
3 CAP; FILLER; RADIATOR; 14PSI; KOMATSU; VE1474  
7 COIL; HD1500-7 KOMATSU; XA3829  
3 TUBE; KOMATSU; EM6272  
1 MAINTENANCE KIT; VEHR; MINOR; SERVICE; KOMATSU HD1500-7; BF3252  
3 PARTS KIT; SHOCK; KOMATSU HD1500-7; BF0694  
5 FRAME; STRUCTURAL; VEH; KOMATSU HD1500-7; EH3653

2 FITTING; KOMATSU HD1500-7; PB9152  
4 RESISTOR; VAR; POTENTIOMETER; KOMATSU HD1500-7; BF4168  
6 CONNECTOR; KOMATSU HD1500-7; 561-95-83820  
4 TUBE STR; SUB COMPONENT OF; BODY EXHAUST COUPLING EJ4467; KOMATSU HD1500-7; EF58;  
1 INLET; WATER ; CONNECTION; CUMMINS QSK78; KOMATSU 860/960 3171098  
11 LENS; LIGHT; FLOOD; NO BULB KOMATSU; AK3337  
1 HOSE ASSY; NONMTL; KOMATSU; HA7311  
1 HOSE; NONMTL; HOIST; KOMATSU; HA7222  
1 HOSE; NONMTL; FLEX; KOMATSU; HA8562  
9 BRACKET; INVERTER; AUX CONTROL CONBINET; 860/960E-2KT KOMATSU; XA5382  
5 V-BELT ; SET ; KOMATSU ;WD500 ; 04121-22563  
3 HOSE; NONMTL; KOMATSU HD1500-7; HA7958  
2 TUBE; KOMATSU; EM6265  
2 BRACKET; 562-06-31390  
8 SEAL; ED0109  
1 BEARING; KOMATSU HD1500; 06030-06224  
1 SHAFT; ROCKER LEVER 4007889  
4 LENS; LIGHT; FLOOD; NO BULB KOMATSU; AK3337  
3 RING; SUPPORT; HYDRAULIC STICK CYLINDER; KOMATSU PC550; 90658940  
1 SENSOR; KOMATSU; 6215-11-8171  
2 VALVE; SOLENOID; HD1500-7 KOMATSU; BF5494  
4 GASKET; KOMATSU HD1500-7; BF3499  
2 REPAIR KIT; KOMATSU HD1500-7; NA74Y49991-10  
4 SWITCH; HD1500-7 KOMATSU; AHPC0485  
2 VALVE; HD1500-7 KOMATSU; BF3264  
4 SWITCH; W/ NUT; KOMATSU HD1500-7; XA2884  
3 LIGHT SERVICE ASS'Y; KOMATSU; 58D-06-10670  
2 HOSE; NONMTL; KOMATSU; HA7942  
4 BAR; BUS; KOMATSU; EL3821  
4 HOSE; KOMATSU HD1500; 02765-00477  
10 TUBE; L-FIN; HD1500-7 KOMATSU; XA3776  
1 HOSE; NONMTL; KOMATSU HD1500-7; HA8112  
2 CUSHION; 566-14-51152  
1 GUARD; 562-89-32220 KOMATSU  
4 CLAMP; EXHAUST; KOMATSU HD1500-7; AHBP4707  
2 BREAKER; CIRCUIT; 12.5 AMP; KOMATASU HD1500-5; PC1385  
21 RING; WEAR; 07156-01417; KOMATSU  
2 CLAMP ASSY; KOMATSU; VW7331  
1 WIRING HARNESS; KOMATSU HD1500-7; 561-95-82430  
2 LIGHT; SIGNAL; TURN; KOMATSU; PC1865  
18 SHIM; KOMATSU HD1500-7; 566-40-42660  
1 PLATE; PARK BRAKE; KOMATSU 561-34-61432  
3 FILTER; KOMATSU;  
1 BOOT ; KOMATSU; EF2238

2 TUBE; KOMATSU; EM6287  
3 FITTING; HD1500-7 KOMATSU; PC1831  
1 HANDLE; KOMATSU 860; EM7207  
2 RING; KOMATSU; PB9417  
1 RING; SNAP; KOMATSU; PB9820  
1 HOSE; NONMTL; KOMATSU; HA8112  
1 TUBE; KOMATSU; EM6264  
1 TUBE; KOMATSU; EM6263  
4 WHEEL BLOWER; HD1500-7 KOMATSU; VE7951  
1 MECHANICAL SEAL; PARTS KIT; HD1500-7 KOMATSU; BF5221  
1 PLATE; BENT; KOMATSU; EM5316;  
1 TUBE; KOMATSU; EM6288  
2 VALVE; FLOW REGULATOR; KOMATSU HD1500-7; XA3837  
4 CABLE; LENGTH 20M MOD BEL-120; KOMATSU ALL FLEET; A0801  
50 SEAL; PLAIN; RUBBER; HD1500-7 KOMATSU; BF3303  
2 HOLDER; 562-46-32590; KOMATSU HD1500  
1 TUBE; KOMATSU; EM6267  
1 TUBE; KOMATSU; EM6261  
2 CABLE; 08028-43090  
1 TUBE; KOMATSU; EM6253  
3 CONNECTOR; KOMATSU HD1500-7; 8296-62-1470  
3 ELBOW; KOMATSU HD1500; 6151-51-8130  
2 PLATE; HD1500-7 KOMATSU; 562-03-31190  
18 CLIP; 07283-36365  
1 TUBE; KOMATSU; EM5665  
1 TUBE; KOMATSU; EM6283  
1 TUBE; KOMATSU; EM6251  
1 TUBE; KOMATSU; EM5666  
1 TUBE; KOMATSU; EM6284  
1 TUBE; KOMATSU; EM6273  
2 GASKET; KOMATSU; 6215-15-4710  
2 HOSE; NONMTL; KOMATSU; HA7113  
10 HARNESS; JUMPER; KOMATSU; EL7606  
1 TUBE; KOMATSU; EM6258  
2 INDICATOR; PC2332 ; KOMATSU HD1500  
6 SWITCH ROTARY; KOMATSU XA4479  
4 CABLE; LENGTH 10M MOD BEL-110; KOMATSU ALL FLEET ; A0803  
5 LIGHT; WORK/REVERSE; HD1500 WATER TRUCK; ENGINEERING TOP TECH; 201-240-34  
1 TUBE; KOMATSU; EM6268  
8 WASHER; HD1500-7; KOMATSU 567-40-41380  
2 PLATE; MUD FLAP; HD1500 KOMATSU; 562-74-31940  
3 BAR; BUS; KOMATSU; EM2054  
1 MOTOR; DC; 24V; HD1500-7 KOMATSU; VE7950  
1 HOSE; FLEX; NONMTL; HD1500-7 KOMATSU; VM4265

1 TUBE; KOMATSU; EM6257  
1 WIRING HARNESS; 426-06-32293  
2 HOSE; FACE SEAL TYPE; KOMATSU HD1500-7; 02762-00443  
1 TUBE; KOMATSU; EM6271  
1 CABLE STRUCTURE; KOMATSU HD1500-7; CH3808  
1 PLATE;KOMATSU HD1500; AH3144  
3 OVERLAY; KOMATSU HD1500-7; XA2885  
1 TUBE; KOMATSU; EM6281  
2 THERMOSTAT; FLOW CONTROL; KOMATSU HD1500-7; BF5256  
12 MOUNT; RESILIENT; RUBBER; HD1500-7 KOMATSU; PC0710  
2 HOSE; NONMTL; DRIVETRAIN KOMATSU; HA6522  
1 TUBE; KOMATSU; EM6256  
10 SEAL; 07016-20758 ; 707-56-75540; KOMATSU HD1500-7  
1 HARNESS; EK9384; KOMATSU HD1500  
18 CLIP; KOMATSU HD1500-7; 04434-51310  
3 CABLE; CH5609  
2 MUDGUARD; EH4125 ; KOMATSU HD1500  
32 NUT; LOCK; KOMATSU HD1500-7; 01596-01615  
17 O-RING; 07000-B5075; KOMATSU  
4 CABLE; LENGTH 15M MOD BEL-115; KOMATSU ALL FLEET ; A0802  
3 PLATE; MUD FLAP; HD1500-7 DUMP TRUCK; KOMATSU; 562-06-31660  
3 SCREW; CAP; FLANGE; HEX HD HD1500-7 KOMATSU; 4001159  
1 TUBE; KOMATSU; EM6252  
4 CABLE; 08028-75025; KOMATSU HD1500  
3 CABLE; CH5745  
2 HOSE; KOMATSU HD1500-7; 02765-00460  
1 VALVE; PILOT; ENGINEERING TOP TECH; 210-457-05  
21 RING; SNAP; 707-75-75110; KOMATSU  
1 CUSHION; 424-01-11320  
1 CUSHION; 424-01-11330  
2 V-BELT; A/C; KOMATSU; 40103100  
1 THERMOSTAT OIL KOMATSU 6218-61-2610  
1 TUBE; KOMATSU; EM6285  
3 SWITCH; KOMATSU HD1500-7; BF2723  
17 BOLT; KOMATSU; 01011-81825  
2 CABLE; BATTERY; RED; KOMATSU; CH3885  
1 HOSE; NONMTL; KOMATSU; HA7958  
2 BRACKET; 562-06-31680  
2 VALVE; GATE; 1.5IN; KOMATSU 785-7; WATER BOWSER; 300106  
4 UNION; 562-43-31230; KOMATSU HD1500-7  
3 PLATE; MTL; CTRL; KOMATSU HD1500-7; XA2883  
50 O-RING; HD1500-7 KOMATSU; 205-62-74580  
1 FLUORESCENT LAMP KOMATSU 76598773  
1 WIRING HARNESS; HD1500-7 KOMATSU; EL7489



2 HOSE; FLEX; NONMTL; HD1500-7 KOMATSU; VM4243  
1 PLATE; KOMATSU; 195-61-62880  
5 LINK; ADJUSTING; AIRCON; AIRCON COMPRESSOR; KOMATSU HD1500-7; 3171103  
1 HOSE; FLEX; NONMTL; HD1500-7 KOMATSU; HA6379  
3 HOSE; NONMTL; HD1500-7 KOMATSU; HA7972  
2 PLATE; 562-06-31670  
2 CAP; VALVE ASSEMBLY; KOMATSU HD1500 566-50-11721  
10 ORING; PLAIN; KOMATSU; XA0172  
20 CLAMP KOMATSU 6217-71-5770  
2 KIT; SEAL; 80 X 70 ENGINEERING TOP TECH; 145-150-02  
4 BAFFLE; AIR; TOP; HD1500-7 KOMATSU; BF5066  
7 BOLT; KOMATSU; 01011-62430  
1 TUBE; KOMATSU; EG0607  
2 BLADE; WIPER; KOMATSU; PB9925  
2 SPACER; DRIVETRAIN; KOMATSU ED1845  
12 CAP; KOMATSU; 6217-71-9770  
5 FLASHER ASSEMBLY; KOMATSU HD1500-7 SM4443  
2 BUSHING; HD1500-7 KOMATSU; 707-52-90520  
1 LIGHT SERVICE ASS'Y; HD1500-7 KOMATSU; 580-06-10670  
2 GASKET; 6215-61-2810; KOMATSU 475  
2 UNION; 56D-61-11360; KOMATSU HD1500 ;  
1 CLAMP; KOMATSU; PB4707  
1 PLUG; DRIVETRAIN; KOMATSU BF5465  
2 CABLE; 08028-43035  
22 SCREW; 6 -32NC X 1/2; KOMATSU 1500; SG2106  
1 TRANSISOR; D155 KOMATSU; ND077800-0750  
1 HOLDER; FILTER; KOMATSU HD1500-7; BF5252  
1 HOSE; NONMTL; FLEX; HD1500-7 KOMATSU; HA7968  
1 HOSE; KOMATSU HD1500; 02767-00440  
1 SWITCH; ENGINEERING TOP TECH; 201-240-39  
3 BLOCK; KOMATSU HD1500; EK5507  
1 PIN; HD1500-7 KOMATSU; 562-74-31991  
2 HOSE ; 07287-01927; KOMATSU HD1500 ;  
4 CLIP; SAFETY; KOMATSU 988758;  
5 HOSE; FACE SEAL TYPE; KOMATSU HD1500-7; 02762-002A6  
1 LINK; HOSE; KOMATSU; EH7753  
1 DECAL; KOMATSU HD1500; AH3143  
4 LAMP; 569-97-82570  
1 INHIBITOR CORROSION; ENG; KOMATSU; XA0177  
1 SWITCH; 2 POSITION; KOMATSU 860E 960E QS0190  
2 JUMPER; HD1500-7 KOMATSU; EK5344  
2 RESISTER; ENG; KOMATSU; 6742-01-4110  
2 SEAL SET; SHAFT; HD1500-7 KOMATSU; BF5222  
8 CUSHION; BATTERY; KOMATSU HD1500-7; 08007-23549

1 HOSE; NONMTL; KOMATSU; BF5079  
4 SCREW; CAP; SKT HD; ENG; KOMATSU; MM0159  
2 GASKET; ENG; KOMATSU; VS2194  
2 JOINT; 561-88-87320 ; KOMATSU HD1500-7; 561-88-87320  
3 HOSE; NONMTL; FLEX; KOMATSU HD1500-7; HA7956  
2 SLEEVE; AIRCON; COMPRESSOR; KOMATSU HD1500-7; 3332237  
1 DISK; KOMATSU HD1500-7; XA2882  
2 O-RING; KOMATSU HD1500-7; 07000-55465  
1 CABLE ASSY; HD1500-7 KOMATSU; CH4312  
11 SCREW; CAP; SKT HD; ENG; MM0031  
2 GASKET; ENG; KOMATSU; VJ4035  
6 INSULATOR; TA7409 ; KOMATSU HD1500  
6 KNOB; AIRCON; CAB; KOMATSU BF5268  
4 RELAY; HD1500-7 KOMATSU; XA3326  
1 HOSE; NONMTL; HD1500-7 KOMATSU; HA7941  
4 TERMINAL; ELECTRICAL; REPAIR; PC5500-6 DBH KOMATSU; 3164292  
6 CLAMP; T-BOLT; KOMATSU HD1500-7; VN3497  
1 ELBOW; 56B-61-13790 ; KOMATSU HD1500 ;  
1 HOSE; NONMTL; DRIVETRAIN KOMATSU; HA6576  
3 JUMPER; HD1500-7 KOMATSU; EK8250  
12 BOLT; M/C; KOMATSU HD1500-7; VN9111  
2 PIN; 562-46-32580 ; KOMATSU HD1500  
1 PLUNGER; KOMATSU HD1500-7; XA2887  
2 END; KOMATSU HD1500-7; 04250-81056  
2 CABLE ASSY; HD1500-7 KOMATSU; CH3419  
1 KIT; SEAL; 125 X 70; ENGINEERING TOP TECH; 145-150-01  
1 HOLDER; FILTER; AIRCON KOMATSU; XA2242  
4 CONNECTOR; ELECTRICAL; PC5500-6 DBH KOMATSU; 3165121  
18 WASHER; HD1500-7 KOMATSU; AHVC6188  
7 CLAMP CUSHIO; ENG; KOMATSU; WB1303  
2 CLAMP; VE5453 ; KOMATSU HD1500  
1 WIRING HARNESS; KOMATSU HD1500 ; 562-43-31250  
1 BRACKET; D155 KOMATSU; 17A-54-46940  
6 ADAPTOR; KOMATSU; HD1500-7; SS0189  
2 CUSHION; EM0071 ; KOMATSU HD1500  
2 CLAMP; ENG; KOMATSU; VE4452  
2 HOUSING; CORE; HD1500-7 KOMATSU; VJ8012  
1 BRACKET; INVERTER; AUX CONTROL CONBINET; 860/960E-2KT KOMATSU; XA5382  
1 SWITCH; KOMATSU; 423-06-45420  
4 COLLAR; KOMATSU HD1500-7; 561-40-42630  
4 O-RING; 6210-61-2520 ; KOMATSU 475  
1 CABLE; HARNESS; PB9957; KOMATSU HD1500  
1 GASKET; WATER TRANSFER; CUMMINS QSK78; KOMATSU 860/960 3649463  
4 SEAL; EM0082; KOMATSU HD1500

4 SEAL; EK8961 ; KOMATSU HD1500  
1 SENSOR ASSEMBLY KOMATSU ND170400-4310  
2 SEAL; KOMATSU; 707-56-75540  
8 ADAPTOR; ASS; KOMATSU; EC2253;  
5 CLAMP; KOMATSU; WA1054  
4 CONNECTOR; TG5601 ; KOMATSU HD1500  
2 GASKET; KOMATSU HD1500-7; BF3500  
2 SEAL; EK8962; KOMATSU HD1500  
1 VALVE; KOMATSU HD1500-7; 566-50-21260  
2 FITTING; WB3397; KOMATSU HD1500 ;  
1 ORING; PLAIN; HYDR; KOMATSU; BF5464  
1 JOINT; KOMATSU HD1500-5; 281-81-12930  
1 RESISTOR; KOMATSU HD1500-7; 600-84-22060  
4 PLATE; KOMATSU HD1500-7; 561-40-42650  
18 PIN; COTTER; HD1500-7 KOMATSU; 04050-18085  
10 SCREW ; KOMATSU HD1500-7; 01310-21216  
3 SEAL; PLAIN; WATER PUMP; CUMMINS; 3033248  
2 SEAL; 569-97-82550  
1 CABLE ASSY; KOMATSU; CH3419  
2 THERMISTOR; ASSEMBLY; D155 KOMATSU; ND077500-5650  
10 O-RING; HD1500-7 CUMMINS; 131026  
2 HANDLE; KOMATSU HD1500-7; GJ138628  
6 SCREW; KOMATSU HD1500; AHWA4605  
1 FITTING; HYDRAULIC; HD1500 KOMATSU; WB0161  
1 GASKET; CUMMINS 3082132  
6 O-RING; KOMATSU; WB1008  
2 SEAL; KOMATSU HD1500; AHEK8961  
2 CLAMP; HD1500-7 KOMATSU AHTF8090  
1 CLAMP; KOMATSU HD785-5; 561-43-62620  
3 SPACER; KOMATSU; 6245-81-6190  
1 SEAL; D RING; KOMATSU HD1500; 3014668  
1 O-RING; KOMATSU 07000-15330  
2 BOLT; KOMATSU 475; 01051-62000  
3 WASHER; FLAT; BRAKE; KOMATSU 281-46-11560  
10 SCREW; CAP; RH; STEP LADDER; KOMATSU; 01010-81010  
1 GASKET; 6693-62-9242  
4 WASHER; KOMATSU; 21W-01-31460  
5 POPPET; AH722187; KOMATSU  
1 FLUORESCENT LAMP KOMATSU 76598773  
3 PIN ; KOMATSU HD1500; 09450-00002  
2 JUMPER; HD1500-7 KOMATSU; EJ2137  
1 BLOCK; CONTACT; ENGINEERING TOP TECH; 250-013-02  
1 SEAL; D RING; KOMATSU HD1500; 4017292  
1 SEAL SET; DUMP TRUCK; HD1500-7 KOMATSU; BF2852

1 SEAL; OIL; KOMATSU HD1500; 3081489  
1 REDUCER; PC1946; KOMATSU; HD1500  
1 CONNECTOR; D155 KOMATSU; 208-979-7650  
8 FUSE; D155 KOMATSU; ND93950-05003  
4 RETAINER; CONNECTOR WIRING INNER; PC5500-6 DBH KOMATSU; 3164261  
4 RETAINER; CONNECTOR WIRING OUTER; PC5500-6 DBH KOMATSU; 3165119  
1 VALVE; REG; HD1500-7 KOMATSU; XA3841  
1 FITTING; WB0162; KOMATSU HD1500 ;  
3 CAPSCREW; HD1500-7 KOMATSU; 80298R1;  
2 GASKET; SM0721 ; KOMATSU HD1500  
3 GASKET; KOMASTU; TZ4987 TZ4987  
1 SCREW; CAP; SKT HD; HD1500-7 KOMATSU; MM0094  
1 ECMV; TRANS; KOMATSU HD1500-7; 562-15-05180  
1 CLAMP; HD1500-7 KOMATSU AHTF8077  
2 LOCKNUT; M6; MM0691 KOMATSU; HD1500  
2 GROMMET; EM0088 ; KOMATSU HD1500  
4 SCREW; CAP; RH; STEP LADDER; HD1500-7 KOMATSU; 01010-81010  
3 CAP; VLV; HD1500-7 KOMATSU; 09282-00022  
2 HOSE; RUBBER; NONMTL; HD1500-7 KOMATSU; EJ2904  
5 BOLT; KOMATSU HD1500-7; 01010-50625  
2 BOLT; KOMATSU HD1500-7; 01010-D1240  
1 CLAMP; HOSE; KOMATSU HD1500-7; 07281-00289  
11 BOLT; 01252-A0625  
4 NUT; KOMATSU; HD1500-7; TR9008  
1 BOLT; KOMATSU HD1500-7; 0101181460  
1 SEAL; O-RING; CYL; HEAD; HD1500-7 KOMATSU; CUMMINS; 4010577  
2 PIN; COTTER; KOMATSU; 04050-23025  
2 PIN; SNAP; 04205-10633; KOMATSU  
2 KEY; WOODRUFF; KOMATSU; 04010-00310  
8 PIN; COTTER; CHASSIS; DUMP BODY HD1500-7; KOMATSU; 04050-15030  
4 BOLT; KOMATSU HD1500-7; 01435-00608  
4 WASHER; KOMATSU HD1500-7; 01641-20508  
1 DECAL HD1500-7 KOMATSU EL3143  
1 GROMMET; VY2784 ; KOMATSU HD1500  
2 O-RING; KOMATSU; WA1732











-31360

